



# Fitting Instructions

DETACHABLE TOWBAR **BM24AQ**  
For BMW 3 SERIES (E90)

## MATERIALS

A	1	Cross Bar
ZQ	1	ZQ3004 Detachable Towball Kit
SEP-M	1	Electrical Plate with type label

## FITTING

1. Remove bumper (screws along lower edge of lower skirt, screws around each wheel arch, 1 tip screw and 1 screw by light cluster on boot shut panel beneath plastic cap, remove light clusters) –prise top edge of bumper off starting at each corner. Where fitted disconnect reversing sensors. Remove lower plastic trim and release exhaust rubber hanger from bumper beam, remove bumper beam - retain original fixings.
2. Secure Cross Bar (A) and **bumper beam** to rear panel using original fixings.
3. **Fully tighten all bolts** and Refit Bumper.
4. Please Refer to ZQ fitting instructions for fitment of the Detachable Neck.
5. Cut area shown below in lower plastic trim.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 (10.9 GRADE)- 139 Nm, M16 - 214 Nm

