



# Fitting Instructions

TOWBAR C27A  
For CITROEN XSARA PICASSO  
2000-

## MATERIALS

A	1	Cross Bar with European facing to 94/20/EC A50-1
D	2	M10 x 90 x 1.5mm Bolts, Nuts, Lock Washers, Flat Washers (20mm O.D.) and Large Flat Washers (40mm O.D.)
D1	4	Bushes (14mm O.D. – 54mm Long)
E	1	Left Hand Side Arm
F	1	Right Hand Side Arm
G	2	M10 x 100 x 1.5mm Bolts, Nuts, Lock Washers, Flat Washers (20mm O.D.) and Large Flat Washers (40mm O.D.)
H	4	M10 x 30 x 1.5mm Bolts, Lock Washers and Flat Washers (20mm O.D.)
J	2	M10 x 30 x 1.5mm Bolts, Lock Washers and Flat Washers (25mm O.D.)
CB	2	M16 x 50 x 2.0mm Coupling Bolts, Nuts and Lock Washers

## FITTING

- Remove spare wheel. Lower rear exhaust hanger. Insert Bushes (D1) into frame from outside faces and loosely attach Side Arms (E) and (F) using Bolts (D) and (G).
- Loosely attach Cross Bar (A) to rear panel mountings using Bolts (J). **Note:** It may be necessary to open up rear panel mounts for Bolts (J). Attach Cross Bar (A) to Side Arms (E) and (F) using Bolts (H)
  - Tighten all bolts. Re-mount exhaust hanger and spare wheel

**Note:** This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

