



# Fitting Instructions

TOWBAR C33  
For Citroen C2 2003-

## MATERIAL

A	1	Cross Bar with European facing to 94/20/EC A50-1
C	4	M10 x 30 x 1.5 pitch bolts, Plain Washers, Lock Washers
CB	2	M16 x 40mm Coupling Bolts, Nuts, Lock Washers

## FITTING

1. Remove the two plastic plugs securing the bottom edge of the bumper skin.
2. The mounting points are covered with sealant tape. Locate their position on the outward facing surface of each chassis rail near its end flange. Carefully remove the sealant tape to expose the threaded mounting holes.
3. Remove the two flanged nuts securing the rearmost rubber exhaust mounting and pull the exhaust mounting off its two studs.
4. Manoeuvre the Cross Bar (A) into position above the exhaust. (Insert RH end of cross bar into space above exhaust and rotate to locate end plate adjacent to chassis mountings. Lift LH Side into position.) Pull the bottom edge of the bumper skin away from the car slightly to increase access. **(Note: Take care to protect the bumper surface from scratches during assembly of the Cross Bar (A)).**
5. Loosely fasten to the outward facing surfaces of the chassis rails using bolts (C).
6. Fully tighten all fasteners.
7. Refit the rubber exhaust mounting and fully tighten its two flanged nuts.
8. Refit the plastic bumper securing plugs.

This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

