



Fitting Instructions

TOWBAR CH14(Q)
For JEEP COMPASS
JEEP PATRIOT
April 2007 -

MATERIALS

A	1	Cross Bar with European facing to 94/20/EC A50-1
E	4	M12 x 110mm Bolts , Nuts, Lock Washers and Washers – 4 x 30mm O.D. 4 x 50mm O.D.
ZQ	1	Neck (ZQ2005)
ZE	1	Electrical Plate (ZEP3)
BC	3	M12 Bolt Caps

FITTING

1. Loosely fit the crossbar (A) using the four pre-bushed holes in chassis rails with bolts (E). **Note** the lugs on the central boot plug may require bending on some models to clear the crosstube.
2. Attach the Neck (ZQ) and Electrical Plate (ZE) using the separate fitting instructions.
3. Fully tighten all bolts to the specified torque as shown below.

Note: This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M12 - 95 Nm M12 (10.9) – 139 Nm

