



Fitting Instructions

TOWBAR SK18
For AUDI Sportback.
Skoda Octavia
Hatch and Estate
(inc VRS)

MATERIALS

A	1	Cross Bar
C	1	Neck with European facing to 94/20/EC A50-1 (ZF3002)
D	4	M12 x 45 x 1.75mm Bolts, Lock Washers and Flat Washers (40mm O.D.)
E	2	M12 x 100 x 1.75mm Bolts (10.9 Grade) and Nyloc Nuts
F	1	ZEP35 Electrical plate (not shown)
ZS	2	Spacers (ZSB1)
CB	2	M16 x 50mm Coupling Bolts, Nuts, Lock Washers

FITTING

1. Remove bumper (5 screws on lower edge, 2 screws beneath light cluster (remove light clusters), 1 screw inside boot beneath light cluster, 1 plastic pin in centre of bumper on boot shut panel, 3 screws and 1 push in clip around wheel arch.) Slide bumper backwards off side panel sliders.
2. Remove the rearmost exhaust hanger and heat shield to allow access to side mountings. Remove crash beam and hand to end user for refitment when bar is removed. **Refit bolts to rear panel to prevent ingress of water.**
3. Insert Cross Bar (A) inside chassis and loosely attach to existing side mountings (remove tape covering holes) using Bolts (D) with Flat Washers. **Fully Tighten Bolts.**
4. Locate centre of bumper and cut as shown below. **(No cut required on VRS)**
5. Loosely secure Neck (C) with Bolts (E) with Spacers (ZS) and fully tighten all bolts.
6. Refit Bumper, exhaust heat shield etc

Note: This towbar must be used with either a Witter Towball (part number Z11) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed.**

Recommended torque settings: M8 - 27Nm, M12 - 95Nm, **Grade 10.9** M12 - 139 Nm, M16 - 214 Nm

